

A.I.S.I. 0-1 GROUND FLAT STOCK

This is an oil hardening, low distortion, precision ground high integrity cold work tool steel widely used for the manufacture of numerous types of industrial tooling.

The main characteristics and properties of the material are:-

- a. High as quenched hardness
- b. Low dimensional movement or distortion after hardening.
- c. Hardens from a relatively low hardening temperature.
- d. Good machinability in the as supplied condition.

These properties are due to the sheets balanced composition which is basically a high carbon steel with the addition of manganese giving some of the properties mentioned above. The additions of Tungsten, Chromium and Vanadium give the steel increased wear resistance, hardenability and the ability to resist gain growth. The steel is supplied in the fully annealed condition with a maximum Brinell hardness of 229HB (50 Tons per Sq. In. Tensile Strength).

Nominal Chemical Composition:-

0.95%
1.20%
0.50%
0.50%
0.20%
0.25% Max.

The steel conforms to AISI 01, BS4659 B01, DIN Werkstoff No. 1.2510.

Typical Applications:-

Blanking Dies	Form Tools	Punches	Gauge Blocks
Gauges	Taps	Dies	Jigs & Fixtures

Form of supply Ground Flat Stock is supplied in the following range:-

	IMPERIAL	METRIC
Thickness	1/32" – 2"	1mm – 50mm
Width	1⁄4" – 14"	6mm – 350mm
Length	18",24",36"	500mm, 1000mm

The steel is protected against corrosion when stored indoors under average conditions for up to 6 months and longer in a good, dry environment with undamaged packaging.

HEAT TREATMENT

Annealing

The steel is supplied in the annealed condition but if it is necessary to re-anneal, the parts should be given some protection such as packing in cast iron turnings. The parts should then be heated to 780°- 800°C, equalised to ensure through heating and held at this temperature for a further 1 hour. Following this, the work is cooled slowly in the furnace at a rate not exceeding 25°C per hour for the first 200°C. A slightly faster rate of cooling after this is allowable.

Sub-Critical Annealing

Where slow cooling or pack annealing is not feasible and or where minimum decarburisation is required sub-critical annealing can be employed. This method consists of heating the steel to 700°C, equalising at this temperature as above followed by furnace cooling to 500°C. After reaching 500°C the parts can be air cooled.

Stress Relieving

This may be advisable if extensive machining has been carried out. Heat the parts slowly to 600°-625°C, equalise and hold at this temperature for 1 hour and air cool.

Hardening

Direct Method (Standard Method)

Heat slowly and uniformly to 790°-810°C depending on section size. Larger work pieces may benefit from a short preheating to and equalising at 650C.

Equalise at 790°-810°C for a period of time depending on section thickness and quench in proprietary quenching oil. Remove the work from the oil whilst still warm (80°-100°C) and temper immediately.

Martempering Method

For tools containing wide changes of section i.e., thin and thick sections, corners or numerous holes the martempering method of hardening is an alternative to the direct quench. This method can help to prevent cracking but necessitates the use of salt bath quenching facilities.

The work piece is heated as for direct hardening but is quenched into molten salt standing at 200°-210°C. Hold in the salt bath until the work has fully equalised at the above temperature (maximum time 8-10 mins) and air cool to 80°-100°C. The work should be immediately tempered.

Page 2 of 5

TEMPERING

Tempering is necessary to relieve residual stress induced hardening and must immediately follow the hardening process ideally whilst the work is still warm. Any delay i.e., due to unavailability of furnace or removal of oil etc., can result in the formation of hardening cracks. Tempering also is required to reduce the as quenched hardness from a typical hardness of 62-63Rc to that required. Typical Rockwell hardness figures against tempering temperatures are given below:-

Tempering Temp.	200°C	Hardness	60Rc
	250°C		58Rc
	300°C		57Rc
	350°C		55Rc

The time required for tempering should not be less than 1 hour. Hardness versus tempering temperature is shown in the chart. Note that a variation of up to +/- several Rockwell "C" points can be expected depending on the variables involved in the hardening and tempering process.

DISTORTION

The minimum degree of distortion in GFS due to quenching and tempering is dependent on the following factors:-

Original Condition	Optimum - Fully annealed
Hardening temperature	Optimum - Lowest consistent with full hardness
Tempering temperature	Optimum – 150°-200°C

When quenched in oil from 790°C this can be expected to give:-

- a. An approximate increase in length of 0.0005" per inch.
- b. An approximate increase in width and thickness of 0.0015" per inch.

When quenched and tempered at 150°C this increase may be reduced by 1/3.

In practice an average dimensional change of plus 0.001" per inch of section may be assumed for GFS oil quenched from 790°C and tempered at 150°C.

Tempering above 200°C may be expected to increase the above figure. These figures do not apply to hardening by martempering method which can be expected to give a marginally higher increase.

Shape distortion

The above figures do not take into account losses due to scaling or shape distortion i.e., bending or sagging due to lack of adequate support.

Page 3 of 5

www.fastenersfixingsandtools.co.uk Tel.01234 333949 Email : info@fasteners-ft.co.uk Fax.01234 211069

FAULT DIAGNOSIS

Faults in hardening can occur and some of the more common reasons and or remedial actions should be applied to try to remedy the problem. These are as follows:-

Low as quenched hardness

Item could have lost too much heat between the furnace and oil bath the hardening furnace temperature may be too low: is this due to faulty furnace instrumentation? Quenching oil too hot, leave to become cooler (within 30°-50°C)

Low Surface hardness

Usually due to decarburised surface. This may be due to hardening temperature being too high or excessive time in the furnace.

High hardness after tempering

Increase tempering time or re-temper at a higher temperature depending on by how much.

Low hardness after tempering (s quenched hardness satisfactory)

Tempering time too long, or tempering temperature too high.

Quench cracks

Most common reason due to excessive time delay between hardening and tempering. High hardening temperature, insufficient time or too long at the hardening temperature, causing decarburisation. Tool not properly quenched, removed from oil too soon, it should not have been hotter than 80°-100°C at time of removal from quenching oil.

Quenching oil too cold – oil temperature should be a minimum of 20C.

Work piece with less simple shapes, sharp changes of section, holes close to edges may require more specialised treatment to reduce the onset of cracking.

Sharp corners and re-entrant angles must be radiussed, holes near edges packed with Kaowool. Heat treatment may include preheating prior to hardening, individual quenching and, if available, martempering.

Deep machining marks or scratches on the tool should be avoided if possible.

All statements made in this document are for guidance only and are made without accepting any liability.



Page 5 of 5